

10' Monticello Set-Up Instructions

Assemble column sections first

Monticello® Column Set Up Instructions

U.S. Patent #5,439,043

1

Magnets on ends

Magnets on ends

Start with the flat, flexible panel...

2

Roll the flat flexible panel into a column shape...

3

The magnets on the ends “snap” together to make the flexible panel round. Place support clips over the magnetic bars **at top and bottom**, to lock them together.

support clip

4

Next, the hubs are placed into both ends of the Column to keep it round...

5

Now, the bottom column is ready to be **Snapped** Magnetically to the unit...
NOTE: some columns may **slide onto** the panels with a **U-channel**.

6

Next, place the top column piece onto the bottom piece, guiding the **square pins** into the **square channels** to hold it in place and keep the magnet strips (or U channel) aligned.

square pins

square channels

1

Left Outside

Right Outside

Sides swing forward after top section is joined.

9' Booth

Begin set-up of center section with **Four Panel Base** between and slightly behind columns .

Insert stacking guides in all sections of base panel.

With center section “accordion” folded, **lower upper section onto base**.
(Shown slightly unfolded in diagram for clarity)

Next, swing sides forward toward columns.

2

Push center hinge forward to make center of display area flat.

Slide entire center section forward and snap the magnets onto the magnetic strips on the columns or insert the side panels' edges into “U” channels on columns.

Set-up is complete and display is ready for graphics.